

# Instructions

Place the mic in the groove so that the element barely protrudes at the center of the mount.



Snap the mount together around the mic.



Use double-sided tape on each side. For extra isolation, use a layer of Sticky Stuff.



Place the mount vertically in between the buttons of the shirt.



The completed mount from the front.

