

# AK4500 Camera Compatibility List (Cable Control)

Brand	Camera lists	Control cable	Function	Setting notes on Camera/Lens	Camera version
Canon	5D MarkIII	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div> <div><div></div>Follow focus electronically</div>	The lens should work in AF mode when Follow focus electronically.	1.3.5
	5D MarkIV	USB 3.0 to Micro 3.0 (A02)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div> <div><div></div>Follow focus electronically</div>	The lens should work in AF mode when Follow focus electronically.	1.1.2
	80D	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div> <div><div></div>Follow focus electronically</div>	The lens should work in AF mode when Follow focus electronically.	1.0.2
	6D	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div> <div><div></div>Follow focus electronically</div>	The lens should work in AF mode when Follow focus electronically.	-
	6D MarkII	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div> <div><div></div>Follow focus electronically</div>	The lens should work in AF mode when Follow focus electronically.	1.0.3
	EOS R	USB 2.0 to TypeC (C01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div> <div><div></div>Follow focus electronically</div>	The lens should work in AF mode when Follow focus electronically.	1.0.0
Nikon	Z7	USB 2.0 to TypeC (C01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div> <div><div></div>Follow focus electronically</div>	1、When controlling with gimbal, please make sure Camera Live view function(LV) is on. 2、The lens should work in AF mode when Follow focus electronically.	1.0.0
	D7500	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div> <div><div></div>Follow focus electronically</div>	1、When controlling with gimbal, please make sure Camera Live view function(LV) is on. 2、The lens should work in AF mode when Follow focus electronically.	1.0.0
Sony	α6300	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div>	1、Set up the USB Connection to PC remote in camera setting menu. 2、Be able to set up Photo storage location in PC remote setting(Camera with old version firmware don't have this feature.	2.00
	α6400	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div>	1、 Select "Network" and then turn off "Ctrl w/Smartphone" in camera setting. 2、Set up the USB Connection to PC remote in camera setting menu. 3、Be able to set up Photo storage location in PC remote setting(Camera with old version firmware don't have this feature.	1.00
	α6500	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div>	1、Set up the USB Connection to PC remote in camera setting menu. 2、Be able to set up Photo storage location in PC remote setting(Camera with old version firmware don't have this feature.	2.00
	RX100 IV	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div>	1、Set up the USB Connection to PC remote in camera setting menu. 2、Be able to set up Photo storage location in PC remote setting(Camera with old version firmware don't have this feature.	1.30
	α7R	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div>	1、Set up the USB Connection to PC remote in camera setting menu. 2、Be able to set up Photo storage location in PC remote setting(Camera with old version firmware don't have this feature.	2.00
	α7SII	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div>	1、Set up the USB Connection to PC remote in camera setting menu. 2、Be able to set up Photo storage location in PC remote setting(Camera with old version firmware don't have this feature.	2.00
	α7RII	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div>	1、Set up the USB Connection to PC remote in camera setting menu. 2、Be able to set up Photo storage location in PC remote setting(Camera with old version firmware don't have this feature.	4.00
	α7II	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div>	1、Set up the USB Connection to PC remote in camera setting menu. 2、Be able to set up Photo storage location in PC remote setting(Camera with old version firmware don't have this feature.	4.00
	α9	USB 2.0 to Micro ( A01)	<div><div></div>Take photos</div> <div><div></div>Start/Stop recording video</div>	1、 Select "Network" and then turn off "Ctrl w/Smartphone" in camera setting. 2、Set up the USB Connection to PC remote in camera setting menu. 3、Be able to set up Photo storage location in PC remote setting(Camera with old version firmware don't have this feature.	2.00